

# Dual Stage Ultrafilter (DSU-H) Install Template

← Allow 8 inch clearance above and below filter connectors to provide enough space for flex hose connections. →

